
EARTHING EQUIPMENT AND FITTINGS









A ROD A ROD **B** COUPLING **B** COUPLING C DRIVING STUD

ROD DIA. LENGTH В мм EARTH ROD COUPLING DRIVING STUD PART NO. PART NO. PART NO. NON EXTENDABLE (9.5 pre-assembled rod and split clamp) 9.5 $^{3}/_{8}$ 1200 4 KEBRSC 9.5 1200 4 KEBR 16 - 1200 KEBFC 16 KEBFD 16 16 5/8

OTHER SIZES AVAILABLE

EARTH ELECTRODE ACCESSORIES



16

ROD DIA. CONDUCTOR SIZE MM²

16 - 70 KECC 16-70



ROD DIA 16 25 x 3 KERTC 25-3



ROD DIA SOLID PART NO. PART NO. KESC T16 KESC 16



ROD DIA KEUB 16

EARTH INSPECTION **CONCRETE INSPECTION PIT INDUSTRIAL PLASTIC INSPECTION PIT**



TYPE PART NO. KEPPIT INDUSTRIAL

PART NO. KECPIT

DOMESTIC PLASTIC INSPECTION PIT



TYPE PART NO. KEPPIT-D DOMESTIC

INDUSTRIAL



KEB 6 450

6 WAY EARTH BAR ON CHANNEL BASE WITH SINGLE DISCONNECTING LINK



LENGTH MM KESLB 6 550


CHANNEL BASE DISCONNECTING LINK




LENGTH MM PART NO.









Email: sales@kompress.com Telephone: 0115 958 1029

EARTHING EQUIPMENT AND FITTINGS





The Kompress Rad-Clamp Earthing Clamp provides simple, effective Earthing for many applications.


Assists installations to meet IEE regulations (BS7671 Section 601-04-02).

Installs on radiator fins or flange.
Installs quickly and simply.


Removes paint, oxide and galvanised coatings. Requires no specialist tolls (8mm Spanner).




Components of Rad Clamp.




Dissassemble all components.




Insert Bolt into Body and position on fitting to be Earthed.




Tighten Bolt with 8mm Spanner until Bolt Head shears.



Fit one M5 Nut to Stud and tigten to act as lock nut.



Fit shake proof washer



Prepare Cable and Crimp into terminal using suitable crimp tool.



Place Terminal over Stud followed by Earth Safety Label and lock into place. Test Earth Connection.

Part No KERC 10



The Kompress Flange-Clamp Earthing Clamp provides simple, effective Earthing for many applications.


Assists installations to meet IEE regulations (BS7671 Section 601-04-02).

Installs on RSJ, staircases and other structural steellwork 3 - 12.5mm Removes paint, oxide and galvanised coatings.


Installs quickly and simply. Requires no specialist tolls (8mm Spanner). For upto 35mm Conductors




Components of Flange Clamp.




Dissassemble all components.




Insert cable between clamp and plate and position on item to be earthed.




Insert M5 bolts into body



Tighten bolts with 8mm spanner until



Fit shake proof washers and 1 M5 nut



Add Earth Safety Label and add a



Tighten M5 nuts and Test Earth Connection.

Email: sales@kompress.com Telephone: 0115 958 1029